

Schwinn 490 Elliptical: Console displays "3 Stuck Button Error" error code

ID: 15319.1

Common issue descriptions:

Error message or error code
3 Stuck Button Error
Button issues/not working

Tools used in this guide: - None -

Estimated time to complete: Less than 5 minutes

Let's get started! We will check the components below to determine which is causing the issue.

1. [Console keypad and buttons](#)

Check the console keypad/buttons

<i>Tools Required:</i>	<i>Estimated Time to Complete:</i>
None	Less than 5 minutes

1. Check for any objects that may be resting on a button. If an object is depressing the button, remove and test if the error clears [\[15319.A\]](#).
2. If the issue persists, [order a Console \[15319.B\]](#).

Need to order replacement parts?

1 Parts Reference Table

<i>Part Description</i>	<i>Part SKU</i>
Console	8027023

2 Contact Tech Team / Advanced Troubleshooting

If the issue was not resolved in the steps listed, contact the Tech Team or send an Advanced Troubleshooting case.

Submit a Case with case type Advanced Troubleshooting