


# BXT8J Treadmill: MCB COMMUNICATIONS TEST (I/O CABLE TEST)

## BXT8J

1. From the **WELCOME** screen, push and hold the **PAUSE/STOP** and **RIGHT** arrow buttons simultaneously for 3 seconds to enter the **Console Setup Mode**. Console will beep and display the **DATE**.



2. Repeatedly push the **OK** button until the Console displays **TOTAL RUN HRS**.



3. Hold down the **PAUSE/STOP** button and **RIGHT** arrow button together for 3 seconds until the Console displays **ENTR MFG TST**.



4. Press the **DOWN** arrow button 13 times until the screen reads **ENTR MCB TST**. **Important!** Do **NOT** press OK at **ENTR MFG TEST**

Categories : **Root / \*NEW\* Troubleshooting Format / Treadmills / BXT8J**  
 Valid from :  
 Valid until :