

BXT8J / T616 / T618: Resetting the Console

Note: Workout data will be lost

1. From the **WELCOME** screen, push and hold the **PAUSE/STOP** and **RIGHT** arrow buttons simultaneously for 3 seconds to enter the **Console Setup Mode**. The Console will beep and display the **DATE**.



2. Repeatedly push the **OK** button until the Console displays **RESET CNSLE N**. Push the **UP** arrow button to change to **CNSLE RESET Y** and press **OK**.



3. The screen will display **RESET START** and will change to **PWR CYCLE NOW**. Power cycle your machine to complete the reset

Categories :

Root / *NEW* Troubleshooting Format / Treadmills / NLS T616

Root / *NEW* Troubleshooting Format / Treadmills / NLS T618

Root / *NEW* Troubleshooting Format / Treadmills / BXT8J

Valid from :

Valid until :