

## BXT8J Treadmill: Error Code 02

### "Procedure 2"

#### **BowFlex BXT8J Treadmill**

1. If the error log is accessed through the service menu, a code will be displayed as either "**CODE 02 COU**" or "**02**" followed by another two-digit number (**reference 1**). The firmware version of the machine determines how the code is displayed.

#### Reference 1



*The beginning of the error log is displayed. Due to different firmware versions, the code is displayed in 2 ways.*

2. Code 2 indicates the beginning of the error log and all machines will display this code. This is not an error and there is no error code-based troubleshooting for these machines.
3. To exit the error log and return to the home screen, power cycle your machine by unplugging it from the wall and plugging it back in [\[14843.A\]](#).

Categories : **Root / Self Service Troubleshooting / BowFlex / Treadmills / BXT8J  
Root / \*NEW\* Troubleshooting Format / Treadmills / BXT8J**

Valid from :

Valid until :