

Schwinn 810 Treadmill - CALIBRATE MCB

Procedure 1

Applies to Schwinn 810 Treadmill only.

1. Stand next to the machine where the console can easily be reached.
 - **Be sure the area around the Treadmill is clear of all bystanders, children and pets.**
 - **Be sure there is nothing on or under the Walking Belt, or near the Treadmill.**
2. Push and hold down the **Pause/Stop** and **Enter** buttons until the machine enters **engineering mode**
3. Push the **Start** button 8 times
4. The calibration procedure will begin by automatically moving the Walking Belt and adjusting the incline of the Walking Deck for about a minute. Then the console will flash and beep.
 - **Be sure not to touch or allow anyone else to touch the machine while calibration is occurring**
5. The calibration procedure is now complete.

Categories :

**Root / *NEW* Troubleshooting Format / Treadmills / Schwinn 810
Root / Self Service Troubleshooting / Schwinn / Treadmills / Schwinn 810**

Valid from :

Valid until :