


# BowFlex Treadmill 7 - CALIBRATE MCB

ID: 13532.2

## "Procedure 4"

**Applicable for the Treadmill 7 only**

**Follow these steps to calibrate the treadmill's MCB**



### **[BowFlex® | How to Calibrate a BowFlex Treadmill](#)**

*Note: This video applies to the Treadmill 7, 10, and 22.*

1. From the Start-Up screen, tap on the upper-right corner of the Console Display 10 times. The Console will display the "**Advanced User Actions**" menu.
2. Tap on the "**Assembly App**" option.
3. From the "**Assembly App**" menu, tap **CALIBRATE** in the upper right corner of the Console Display. The Console will shift to Calibrate mode.
4. From the "**Calibrate**" menu, tap **BEGIN TEST SUITE**.
  - Be sure the area around the Treadmill is clear of all bystanders, children and pets.
  - Be sure there is nothing on or under the Walking Belt, or near the Treadmill.
5. The Console will display "**CALIBRATE\_MCB-USER CONFIRM**". Tap **CONFIRM**, and the calibration procedure starts.
  - Note: The calibration procedure will begin by automatically moving the Walking Belt and adjusting the incline of the Walking Deck. **Be sure not to touch or allow anyone else to touch the machine while calibration is occurring.**
6. When calibration is complete, the Console will display "**CALIBRATE MCB - PASS**".
7. Tap **EXIT** in the upper-right corner of the Display to exit the Calibrate Mode.
8. Flip the power switch to OFF. Calibration is now complete for the machine.

## **Need additional assistance?**

### 1 Customer Care Contact Information

**Please contact Customer Care at [1-800-605-3369](tel:1-800-605-3369) for additional help or to order replacement parts. Some replacement parts may also be available for purchase [online here](#). A list of part numbers referenced within this guide can be located at the bottom of this page.**

**Customer Care - Hours of Operation:**

**Monday - Friday 6:00am - 5:00pm PST**

*The replacement part will be provided to you at no cost assuming your machine meets the warranty eligibility requirements. A Customer Care Agent will be able to assess your current warranty eligibility and provide you with your options.*

*Please note that if you did not purchase your machine directly from BowFlex, Schwinn, or Nautilus, we will need a copy of your purchase receipt in order to register your machine for warranty.*

### 2 Contact Tech Team / Advanced Troubleshooting (TM/TC)

***If the issue was not resolved in the steps listed, contact the Tech Team or send an Advanced Troubleshooting case.***

**Submit a Case** with case type **Advanced Troubleshooting**

---

**Use these procedures as needed to gather more information to create the case:**

**[Results Series Treadmills Procedures](#)**

**[Treadmill 7 Procedures](#)**

**[Treadmill 10 Procedures](#)**

**[Treadmill 22 Procedures](#)**

**[MY14/17 Treadmill Procedures](#)**